

# Part 3

## Mutual Inductance




# Main Outlines


- ☐ Review of self inductance
- ☐ Concept of mutual inductance
- ☐ Mutual inductance in terms of self inductance
- ☐ Polarity of the mutually induced voltages (**Dot Convention**)
- ☐ Procedure for determining dot marking
- ☐ Use of dot markings in circuit analysis
- ☐ Energy calculations




# Magnetic Field



(a) Permanent magnet



(b) Field around a straight wire carrying current  $I$



(c) Field for a coil of wire

Magnetic fields  
can be visualized  
as **lines of flux**  
that form closed  
paths

The flux  
density vector  
**B** is tangent to  
the lines of flux




# Magnetic Field

- Magnetic flux lines form closed paths that are close together where the field is strong and farther apart where the field is weak
- Flux lines leave the north end (pole) of a magnet and enter the south end (pole)
- When placed in a magnetic field, a compass indicates north in the direction of the flux lines




# Magnetic Field


- A wire carrying a current  $I$  causes a **magneto-motive force** (m.m.f)  $F$
- this produces a **magnetic field**
  - $F$  has units of Amperes
  - for a single wire  $F$  is equal to  $I$



# Magnetic Field



(a) If a wire is grasped with the thumb pointing in the current direction, the fingers encircle the wire in the direction of the magnetic field



(b) If a coil is grasped with the fingers pointing in the current direction, the thumb points in the direction of the magnetic field inside the coil

## Right-Hand Rule



# Magnetic Field

- The magnitude of the field is defined by the **magnetic field strength (intensity)**,  $H$ , where

$$H = \frac{I}{l}$$

where  $l$  is the length of the magnetic circuit

- The magnetic field produces a **magnetic flux**,  $\Phi$ 
  - flux has units of weber (Wb)
- Strength of the flux at a particular location is measured in term of the **magnetic flux density**,  $B$ 
  - flux density has units of tesla (T) (equivalent to 1 Wb/m<sup>2</sup>)





# Magnetic Field


- Flux density at a point is determined by the field strength and the material present

$$B = \mu H$$

or

$$B = \mu_0 \mu_r H$$

- ✓ where  $\mu$  is the permeability of the material,  $\mu_r$  is the relative permeability and  $\mu_0$  is the permeability of free space
- Adding a ferromagnetic ring around a wire will increase the flux by several orders of magnitude, since  $\mu_r$  for ferromagnetic materials is 1000 or more






# Magnetic Field

- When a current-carrying wire is formed into a **coil**, the magnetic field is **concentrated**
- For a coil of  $N$  turns the m.m.f. ( $F$ ) is given by:

$$F = IN$$

and the field strength is

$$H = \frac{IN}{l}$$



# Magnetic Reluctance

- In a *resistive circuit*, the resistance is a measure of how the circuit opposes the flow of electricity
- In a *magnetic circuit*, the **reluctance**,  $\mathfrak{R}$  is a measure of how the circuit opposes the flow of magnetic flux

✓ In a resistive circuit  $R = V/I$

✓ In a magnetic circuit  $\mathfrak{R} = \frac{F}{\Phi}$

- the units of reluctance are amperes per weber (A/ Wb)

- The magnetic **Permeance** is given by:  $P = \frac{1}{\mathfrak{R}}$



# Flux Linkages and Faraday's Law

- Magnetic flux passing through a surface area A:

$$\phi = \int_A \mathbf{B} \cdot d\mathbf{A}$$

- For a constant magnetic flux density perpendicular to the surface:  $\phi = B A$

- The flux linking a coil with N turns:

$$\lambda = N \phi$$



# Faraday's Law

## □ Faraday's law of magnetic induction:

$$e = \frac{d\lambda}{dt}$$



□ The voltage induced in a coil whenever its flux linkages are changing.

□ Changes occur from:

- Magnetic field changing in time
- Coil moving relative to magnetic field



# Faraday's Law



# Lenz's Law


□ Lenz's law states that the **polarity** of the induced voltage is such that the voltage would produce a current (through an external resistance) that **opposes** the original change in flux linkages.

- Induced voltage at every instant opposes any change in circuit current
- The current in a conductor, as a result of an induced voltage, is such that the change in magnetic flux due to it is opposite to the change in flux that caused the induced voltage






# Lenz's Law



When the flux linking a coil changes, a voltage is induced in the coil. The polarity of the voltage is such that if a circuit is formed by placing a resistance across the coil terminals, the resulting current produces a field that tends to oppose the original change in the field.



# Lenz's Law



- When  $I$  changes, an emf is induced in the coil
- If  $I$  is increasing (and therefore increasing the flux through the coil), then the induced emf will set up a magnetic field to oppose the increase in the magnetic flux in the direction shown.
- If  $I$  is decreasing, then the induced emf will set up a magnetic field to oppose the decrease in the magnetic flux.




# Magnetically Coupled Circuits

- When two loops with or without contacts between them affect each other through the magnetic field generated by one of them, it called *magnetically coupled*
- **Example: transformer**
  - ✓ An electrical device designed on the basis of the concept of magnetic coupling
  - ✓ Used magnetically coupled coils to transfer energy from one circuit to another



# Transformers and Power Transmission

- Electric power is most efficiently transmitted at high voltages.
  - This reduces  $I^2R$  energy losses in the power lines.
  - But most end uses require lower voltages.
  - Transformers accomplish voltage changes throughout the power grid.



# Self and Mutual Inductance

## □ 1 coil (inductor)


- Single solenoid has only self-inductance ( $L$ )

## □ 2 coils (inductors)

- 2 solenoids have self-inductance ( $L$ ) & Mutual-inductance



# Self Inductance




- ✓ A coil with  $N$  turns produced  $\phi = \text{magnetic flux}$
- ✓ Only has self inductance,  $L$





# Self Inductance

**Self-inductance:** If the current  $i$  in the coil is changing, the changing flux through the coil induces an emf in the coil.




The current  $i$  in the circuit causes a magnetic field  $\underline{B}$  in the coil and hence a flux through the coil. When the current changes, the flux changes also and a self-induced emf appears.



# Self Inductance

- It called *self inductance* because it relates the voltage induced in a coil by a time varying current in the same coil
- Consider a single inductor with  $N$  number of turns when current,  $i$  flows through the coil, a magnetic flux,  $\Phi$  is produces around it



# Self Inductance

- According to Faraday's Law, the voltage,  $v$  induced in the coil is proportional to  $N$  number of turns and rate of change of the magnetic flux,  $\Phi$ ;

$$v = N \frac{d\phi}{dt} \dots\dots(1)$$

- But a change in the flux  $\Phi$  is caused by a change in current,  $i$ . Hence;

$$\frac{d\phi}{dt} = \frac{d\phi}{di} \frac{di}{dt} \dots\dots(2)$$



# Self Inductance

➤ Thus, (2) into (1) yields;

$$v = N \frac{d\phi}{di} \frac{di}{dt} \dots\dots\dots(3)$$

or

$$v = L \frac{di}{dt} \dots\dots\dots(4)$$


➤ From equation (3) and (4) the self inductance L is define as;

$$L = N \frac{d\phi}{di} \quad (\text{H}) \dots\dots\dots(5)$$

✓ The unit is in Henry (H)



# Self Inductance (conclusions)



Magnetic field

$$\lambda = N\Phi$$


Total magnetic flux linked by  $N$ -turn coil

$$v = \frac{d\lambda}{dt}$$

Faraday's Induction Law

$$\lambda = Li$$

Ampere's Law




$$v = L \frac{di}{dt}$$

Ideal Inductor




# Resistor and Inductor



$$V_{ab} = iR$$

(a) Resistor with current  $i$  flowing from  $a$  to  $b$ :  
potential drops from  $a$  to  $b$

Potential difference across a resistor depends on the current



$$V_{ab} = L \frac{di}{dt}$$

(b) Inductor with current  $i$  flowing from  $a$  to  $b$ :

- If  $di/dt > 0$ : potential drops from  $a$  to  $b$
- If  $di/dt < 0$ : potential increases from  $a$  to  $b$
- If  $i$  is constant ( $di/dt = 0$ ): no potential difference

Potential difference across an inductor depends on the **rate of change** of the current






# Inductor

- The inductance of a coil depends on its dimensions and the materials around which it is formed


$$L = \frac{\mu_0 AN^2}{l}$$



(a) An air-filled coil



# Types of Inductors



$$L = \frac{\mu_0 \mu_r A N^2}{l} = \frac{N^2}{\mathfrak{R}} = N^2 P$$

$$\mathfrak{R} = \frac{1}{P} = \frac{l}{\mu_0 \mu_r A}$$





# Factors Affecting Inductance of Coils

- ✓ **Numbers of Turns-** Inductance varies directly with the square of the number of turns
- ✓ **Permeability of Core-** Inductance varies directly with the permeability of the core
- ✓ **Cross-sectional Area of Core-** Inductance varies directly with the cross-sectional area of the core
- ✓ **Length of Core-** Inductance varies inversely with the length of the core



# Mutual Inductance

- ❑ **Mutual inductance** occurs when a changing current in one circuit results, via changing magnetic flux, in an induced emf and thus a current in an adjacent circuit
  - Mutual inductance occurs because some of the magnetic flux produced by one circuit passes through the other circuit



# Mutual Inductance

- ❑ When two inductors or coils are in close proximity to each other, magnetic flux caused by current in one coil links with the other coil, therefore producing the induced voltage
- ❑ The coils are said to have mutual inductance  $M$ , which can either add or subtract from the total inductance depending on if the fields are aiding or opposing
- ❑ **Mutual inductance** is the ability of one inductor to induce a voltage across a neighboring inductor






# Mutual Inductance

Consider the following two cases:

## □ Case 1:

two coil with self – inductance  $L_1$  and  $L_2$  which are in close proximity which each other. Coil 1 has  $N_1$  turns, while coil 2 has  $N_2$  turns.





# Mutual Inductance

➤ Magnetic flux  $\Phi_1$  from coil 1 has two components;

\*  $\Phi_{11}$  links only coil 1

\*  $\Phi_{12}$  links both coils

✓ Hence;  $\Phi_1 = \Phi_{11} + \Phi_{12} \dots\dots\dots (6)$

✓ Thus; the voltage induces in coil 1

$$v_1 = N_1 \frac{d\phi_{11}}{di_1} \frac{di_1}{dt} = L_1 \frac{di_1}{dt} \dots\dots\dots (7)$$



# Mutual Inductance

- ✓ The Voltage induces in coil 2


$$v_2 = N_2 \frac{d\phi_{12}}{di_1} \frac{di_1}{dt} = M_{21} \frac{di_1}{dt} \dots\dots(8)$$

Subscript 21 in  $M_{21}$   
means the mutual  
inductance on coil 2  
due to coil 1



# Mutual Inductance

□ **Case 2:** Same circuit but let current  $i_2$  flow in coil 2.



✓ The magnetic flux  $\Phi_2$  from coil 2 has two components:

- \*  $\Phi_{22}$  links only coil 2.
- \*  $\Phi_{21}$  links both coils.

Hence;  $\Phi_2 = \Phi_{21} + \Phi_{22} \dots\dots\dots (9)$



# Mutual Inductance

- ✓ Thus; the voltage induced in coil 2

$$v_2 = N_2 \frac{d\phi_{22}}{di_2} \frac{di_2}{dt} = L_2 \frac{di_2}{dt} \dots\dots(10)$$

- ✓ the voltage induced in coil 1

$$v_1 = N_1 \frac{d\phi_{21}}{di_2} \frac{di_2}{dt} = M_{12} \frac{di_2}{dt} \dots\dots(11)$$

Subscript 12 in  $M_{12}$   
means the Mutual  
Inductance on coil 1 due  
to coil 2



# Mutual Inductance


- Since the two circuits and two current are the same:

$$M_{21} = M_{12} = M$$


- Mutual inductance M is measured in Henrys (H)




# Mutual Inductance (conclusions)



**a) Magnetic flux produced by a single coil**



**b) Mutual inductance  $M_{21}$  of coil 2 with respect to coil 1**



**c) Mutual inductance of  $M_{12}$  of coil 1 with respect to coil 2**





# Terms & Definitions

- ✓ **Inductor-** A device that introduces inductance into an electrical circuit (usually a coil)
- ✓ **Inductance-** The property of an electric circuit when a varying current induces an EMF in that circuit or another circuit
- ✓ **Self-inductance-** The property of an electric circuit when an EMF is induced in that circuit by a change of current
- ✓ **Henry -** The unit of inductance
- ✓ **Permeability-** The measure of the ease with which material will pass lines of flux
- ✓ **Mutual Inductance-** The property of two circuits whereby an EMF is induced in one circuit by a change of current in the other

